



1 Make a space into the concrete slab using XPS or plywood.

Sitto Trimless 1x1 205x205x150 mm

Sitto Trimless 2x1 205x335x150 mm



2 Install box.



3 Level inside frame (between 2-20mm). Plaster and paint.

